

Gesipa NTX, NTX F



Инструкция по эксплуатации

1.

Ø 5

Ø 4

2.

NTX/NTX-F – 1 (NTX-F)

10/18 – 1 (NTX)

10/24 – 1 (NTX, NTX-F)

10/27 – 1 (NTX-F)

10/32 – 1 (NTX, NTX-F)

SW10 – 1

3.

Ø		
2,4		10/18
3,2	CAP -	10/18
3 3,2	, , ,	10/24
4	,	10/24
4	, CAP - , CAP-	10/27
4		10/29
4,8	CAP -	10/29
4,8 5		10/32

4.

- (8)
- (7/7F) (6)
- (5), , . - .
- .

5.

- .
- (4 - 8) , 4,
(1/1F).
- , .
- (2/2F) (9) (12).
- , (9) (4).
- NTX-F - (20F)

